USER MANUAL

MI 411 Free & Total Chlorine and pH Meter





Dear Customer.

Thank you for choosing a Martini product. This manual will provide you with the necessary information for the correct use of the instrument. Please read it carefully before using the meter. This instrument is in compliance with

€directives.

SPECIFICATIONS:

Free & Total Chlorine

0.00 to 5.00 mg/L CI2 Range Resolution 0.01 mg/L (0.00-3.50 mg/L); 0.10 mg/L (above 3.50 mg/L) **Precision** ±0.04 mg/L @ 1.50 mg/L Method Adaptation of the USEPA method 330.5 and Standard Method 4500-CI G.

pН

Range 6.5 to 8.0 pH Resolution 0.1 pH Precision ±0.1 pH @ 7.2 pH Method Adaptation of the phenol red method.

Other

Light Source Tungsten lamp Silicon Photocell and 525 nm **Light Detector** narrow band interference Environment 0 to 50°C (32 to 122°F); 100% RH max. **Battery Type** 1 x 9 volt Auto-Shut off After 10' of non-use **Dimensions** 192 x 104 x 52 mm (7.5 x 4.1 x 2") Weight 380 g

CHANGE PARAMETER

To change parameter between Free &Total Chlorine and pH. press and hold for 3 seconds, the ZERO key. The selected parameter will be displayed (chlorine) or "PH" on the display.




MEASUREMENT PROCEDURE:

- 1• Turn the meter on pressing ON/OFF. The last selected parameter displayed on the Liquid Crystal Display ("Cl" or "PH").
- 2. Choose the parameter that vou want to measure.
- 3. Fill the cuvet with 10 mL of unreacted sample, up to the mark, and replace the cap.
- 4. Place the cuvet into the holder and ensure that the notch on the cap is positioned securely into the
- 5. Press ZERO and "SIP" will blink on the display.
- 6. After a few seconds the display will show "-0.0-". The meter is now zeroed and ready for measurement.



For Free Chlorine measurement

7 •Add 3 drops of DPD 1 reagent and 3 drops of DPD 2 reagent to an empty cuvet. 8. Immediately add 10 mL of unreacted sample. Replace the cap and shake gently.



- Immediately reinsert the cuvet into the holder and ensure that the notch on the cap is positioned securely on the groove
- Press READ and "SIP" will blink during measurement.



11. The instrument directly displays concentration in mg/L of free or total chlorine.

Interferences:

- Bromine (positive error)
- Chlorine dioxide (positive error)
- Iodine (positive error)
- Oxidized Manganese (positive error)

- Chromium (positive error)
- Ozone (positive error)

For Total Chlorine measurement

- 12. Remove the the cuvet and add to the reacted sample 3 drops of DPD 3 reagent. Replace the cap and swirl gently.
 - 13. Reinsert the cuvet into the holder and position securely into the groove.
- 14 Wait for 2 minutes 30 seconds then press READ and "SIP" will blink during measurement.
- 15• The instrument dirrectly displays concentration in mg/L of total chlorine.

For pH measurement

- 16. Fill a cuvet with 10 mL of unreacted sample up to the mark.
- 17. Add 5 drops of pH-0 reagent. Replace the cap and shake
- 18. Insert the cuvet into the holder and ensure that the notch of the cap is positioned securely into the groove.
- 19. Pres READ and "SIP" will blink during measurement.
- 20• The instrument dirrectly display the pH value.

GUIDE TO DISPLAY CODES:

This prompt appears for 1 second each time the instrument is turned on.



Ax5



Sampling In Progress. Flashing "SIP" prompt appears each time the meter is performing a measurement.

"-0.0-", the meter is in a zeroed state and measurement can beperformed.




The blinking "BAT" indicates thatb the battery voltage is getting low and the battery needs to be replaced.



-68-

"-bA-", the battery is dead and must be replaced. Once this indication is displayed, the meter will lock up. Change the battery and restart the meter.





ERROR MESSAGES

On zero reading

- Blinking "-0.0-" indicates that the zeroing procedure failed due to a low signaltonoise ratio. In this case press ZERO again.
- "no L". the instrument cannot adjust the light no L level. Please check that the sample does not contain any debris.



- "L Lo", there is not enough light to perform a measurement. Please check the preparation of the zerocuvet.
- "L Hi". there is too much perform liaht to н, measurement. Please check the preparation of the zero cuvet.

On sample reading

- "-SA-". there is too much light for the sample measurement. Please check if the right sample cuvet is inserted.
- "Inv". the sample and the zerocuvet are inverted.
- "ZErO", a zero reading was not taken. Follow the instruction in the measurement procedure for zeroing themeter.
- Under range. A blinking "0.00" indicates that the sample absorbs light than the zero reference. Check the procedure and make sure you use the same cuvet for reference (zero) and measurement.
- A flashing value of the maximum concentration indicates an over range condition. The concentration of the sample is beyond the programmed range: dilute the sample and re-run the test.

BATTERY REPLACEMENT

Battery replacement must only take place in a non-hazardous environment. Simply rotate the battery cover on the back of

battery from the the terminals and attach a fresh 9V battery while paving attention to the correct polarity. Insert the battery and replace the cover.

the meter. Detach

ACCESSORIES:

- 58 -

inu

2E-0

MI504-100 Free & Total Chlorine reagent set (100

MI509-100 pH reagent (100 tests)

MI511-100 Free & Total Chlorine and pH reagent set (100 tests)

MI0001 Glass cuvets (2 pcs) MI0002 Caps for cuvets (2 pcs)

MI0003 Stoppers for cuvets (2 pcs) MI0004 Tissue for wipping cuvets (4 pcs)

MI0005 9V battery (1 pc)

WARRANTY

This instrument is warranted against defects in materials and manufacturing for a period of two years from the date of purchase.

If during this period the repair or replacement of parts is required, where the damage is not due to negligence or erroneous operation by the user, please return the meter to either distributor or our office in the original packing and the repair will be free of charge.

Damages due to accidents, misuse, tampering or lack of prescribed maintenance are not covered.